



/ Main/Backup Switcher Desktop

DATA AND DMX DISTRIBUTION



The TecArt Main/Backup Switcher is primarily used for main and backup consoles. The unit automatically detects incoming DMX512, and automatically switches to the backup DMX stream as soon as the main input is disconnected or lost.

The TecArt Main/Backup Switcher can also be used to connect an external console to a live DMX network and will automatically switch over to take control.

The units are available with a choice of 3 or 5 pin connectors.

Main/Backup Switcher Desktop