



/ Main/Backup Switcher Rack Mount

Mount

DATA AND DMX DISTRIBUTION



The TecArt Main/Backup Switcher is primarily used for main and backup consoles. The unit automatically detects incoming DMX512, and automatically switches to the backup DMX streams as soon as the main inputs are disconnected or lost.

The TecArt Main/Backup Switcher can also be used to connect an external console to a live DMX network and will automatically switch over to take control.

The unit is available with up to 4 main DMX streams and 4 backup DMX streams. The inputs are connected via front panel XLR connectors and the output connectors are on the rear of the unit. Each input/output has a separate power supply and is electrically isolated to ensure the highest possible level of protection.

The units are available with a choice of 3 or 5 pin connectors, and are also available in 1, 2 or 3 inputs/outputs.

Main/Backup Switcher Rack Mount